

LG Information

Models GDK/LDK/NEXER

Date and time - **GDK 34i / 100 / 186 Systems**

From the Attendant (usually ext 100)

Press [Trans/PGM]

Dial # then 1

Enter Date + Time as YY/MM/DD HH:MM

(YY = Year 00-99 MM = month 01-12 DD = day 01-31 HH = Hour 00-23 MM = minute 00-59)

[Hold/Save]

For the - **LDK100/ LDK300/LDK24 (Nexer) system**

From the Attendant phone: (usually ext 100)

Press [TRS/PGM]

dial 041

Dial the date (MM/DD/YY)

Press [Hold/Save]

Dial time (HH:MM)

Press [Hold/Save]

For the - **GDK 16/16A/16E/20W Systems**

From the Attendant

Press TRANS/PGM button

Dial #1

Enter Date + time - enter as YY/MM/DD HH:MM

(YY = Year 00-99, MM = Month 01-12, DD = Date 01-31, HH = Hour 00-23 mm = Minutes 00-59)

If there is no need to change date or time, press * key i.e.

YYMMDD + * or *+HHMM

[Hold/Save]